www.joyoaudio.com

JAM BUDDY | 用户使用说明

JOYO

FEEL JOYO ENJOY MUSIC

JAM BUDDY | User Manual

www.joyoaudio.com

JOYO

FEEL JOYO ENJOY MUSIC

感谢您购买我们的产品!

产品概述

JAM BUDDY 是一款针对吉他手设计的便携式压缩音箱，它结合了吉他音箱和意不尽延续功能，内置一块锂电池，为吉他手提供了它为单点全频音染的便利性，您可以使用这平摄前音乐，选择您喜欢的音色进行演奏。

JAM BUDDY 采用超紧凑设计，每个通道按钮独立的增益调节，音色包括清音，过载和失真，并具有可独立调节效果深度，时值和反馈时间的延时效果器，通过混响控制创造空色，为您的演奏带来了更多更时性和乐趣。

JAM BUDDY 不仅提供了丰富的吉他音色效果，并能的直手播放功能，而且体型小巧的特点更为便您随时随地携带在身边练习吉他，进行你个人的JAM TIME!

更多产品信息，请关注官方微信

重要的安全说明

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

注意，机内无用户可维备件！ 为了防止触电,切勿自行拆开机盖！ 必要时需由专业人士维修!

警告：为防止发生火灾或触电危险,本机切勿受雨淋或受潮!

等边三角形中带有的闪电型箭头,该符号旨在警告用户——机内具有危险电压的非绝缘部分,易造成电击的危险。

等边三角形中带有的感叹号,该符号用来提醒用户——机器附件中有重要的操作和保养说明,请查阅使用说明书。

该符号警告用户——禁止推移在最顶端没有机箱固定无保护措施的可移动机架,滑轨最顶端的机箱跌落危险警告禁止必要时人为保养。为保护您的利益,请使用由制造商推荐的型号的移动机架、三角架、脚架、固定架、控制台等配件。

严重警告 无论本机是在充电还是接电源适配器想用时,机器正处于与电网电源连接的状态,为防止发生火灾或触电危险,切勿自行拆开机盖进行维修和维护!

详细的安全说明

- 为了您的安全和避免损地愚伤使用本产品,使用前请先详细阅读并理解本书中有的安全与使用说明。
- 为了防止以造更加方便地使用和保存本产品,请妥善保管好本使用说明书以供必要时查阅。
- 为了您能更加安全地使用本产品,请遵守在设备上和说明书中所有的警告与注意事项。
- 只使用厂商指定的安全附件和本机一起卖出的零件与附件。擅自物品可能会本机。
- 严禁将本机及AC电源适配器放置在潮湿的地方使用,如浴室、厨房、洗衣机、屋顶或室外。请注意避免,防止液体溅入机内,以免造成火灾或触电危险。如液体或金属物体掉入机内,请立即关闭电源,拔掉电源线,并请专业人员检查后再使用。
- 本机内没有任何可由用户进行维修的部件。请不要拆开机器或改装内部电路。如果机内有异常,请与您的当地经销商或JOYO客服中心联系。
- 如果长期不使用本机,请将电源线从电源插座上拔下,以免因雷雨或过电压造成损坏。
- 为防止电源线损坏,请勿对电源线过度弯曲,避免造成线路断裂而损伤,有请请小型对可干扰有影响。
- 不要将电源线放置在热源附近,以免塑料外皮熔化。
- 为防止发生火灾,请及时为本机充电。过度放电以及内部电池长期耗电会导致不可逆的电池容量损失,导致电池报废。

面板说明



1. 延时效果器 / 混响效果音量钮；
2. 延时效果器反馈深度调节旋钮；
3. 延时效果器延时时间调节旋钮；
4. 总输出音量调节旋钮；
5. 音色核心处理音量钮；
6. 过载通道增益调节旋钮；
7. 清音通道增益调节旋钮；
8. 蓝牙指示灯：当JAM BUDDY的蓝牙功能被打开时，蓝牙指示灯点亮为蓝色灯。
9. 电源/电池电量指示灯：开启JAM BUDDY后，电源指示灯点亮为蓝色灯,当电池电量不足时,指示灯将开始持续以每秒两指闪烁的方式，以提醒JAM BUDDY将自动关机。
10. 音色通道模式选择 **公共**：当您离这载模式被选中时音色通道会以红色。
11. 高增益模式开关 **公共**：当高增益模式被选中时，该指示灯点亮。
12. 电源开关：开启关闭JAM BUDDY设备的电源。
13. 蓝牙开关：开启关闭JAM BUDDY的蓝牙功能。
14. 过载通道指示灯：
15. 清音通道指示灯：
16. 过载通道模式选择按钮：
17. 通道切换按钮：
18. 立体输入接口：
19. 环境输出接口：注意，耳机接入后，本机的喇叭输出将自动被切断。
20. 电源接口：连接电源适配器的接口。

基本操作说明

1 将吉他与JAM BUDDY连接

2 打开电源开关

3 电源指示灯：清音通道指示灯与开关过载模式指示灯同时亮起/熄灭表示：本机开机状态正在等待音通道

4 ROCK NOW! 您可根据您的演奏需求调节TONE、DRIVE GAIN、CLEAN、PRESENCE和MASTER VOLUME旋钮来获得合适的吉他音量。

5 您可通过操作通道选择按钮来选择您需要的音色通道。当指示灯亮起表示选择了：对应的通道音色处于启动状态。

6 您还可以通过操作过载通道开关选择踏板来调整DRIVE通道，使其工作在CLASSIC模式或者HIGH GAIN模式。当指示灯熄灭表示选择了：对应的模式处于关闭状态。

7. JAM BUDDY为您提供了蓝牙无线输出接口，您可以通过此接口连接耳机，这样您就可以实现静音练习或者演奏音乐，并且不会打扰到别人。

8 JAM BUDDY内置一只标准的3.5mm立体声耳机输出接口，您可以通过此接口连接耳机，这样您就可以实现静音练习或者演奏音乐，并且不会打扰到别人。

注意：如果您正在使用JAM BUDDY的DRIVE通道，请尽量避免将JAM BUDDY的音量旋钮调整在过高位置，这样可能会引起啸叫。

蓝牙连接

JAM BUDDY内建有蓝牙通信单元，你可以使用带有蓝牙功能的设备与JAM BUDDY进行连接并播放音乐。要使用本功能，您可以按照下面的方式来操作您的JAM BUDDY。

①打开JAM BUDDY蓝牙开关，蓝牙指示灯点亮为蓝色表示待配对状态。

②打开移动设备的蓝牙功能，在设备列表中找到「JAM BUDDY」，并进行配对，成功配对后，JAM BUDDY的蓝牙指示灯将保持常亮状态。

充电

在使用JAM BUDDY过程中，如果电源指示灯变成黄色灯闪烁时，则表示您需要给JAM BUDDY充电了，为了不影响内置电池，请不要长期让本机处于低电状态工作，如不使用，请将电池充满存放。

注意事项

①将电源适配器接通JAM BUDDY电源接口进行充电。

②为JAM BUDDY充电时，充电指示灯点亮为红色灯。

③当JAM BUDDY充满电后充电指示灯熄灭。

注意事项 请使用本产品配备的电源适配器进行充电。

温馨提示： 如果电池已经完满电，即电池使用时间不足1小时，说明电池已经老化，您需要更换新电池再使用。

电气参数

AC适配器输入电压： AC100~240V 50~60Hz
AC适配器输出电压： DC 9V/3A
内置电池规格： 1.2V/2500mAh(锂电池)
吉他通道输入阻抗： >6.7dBV
RMS功率： (W + W + W)
效果器-吉他通道： DELAY(最大500ms)
重量：600g
体积：156（长）X103（宽）X75（高）mm

产品信息登记

销售商名	姓名
销售商电话	QQ 号
日 期	

产品质量保证卡

产品型号		购买日期	
用户信息	姓名	电话	
	地址		
	邮政编码		
销售单位信息	销售商名称	电话	
	地址		

产品质量保证条款

1、在正常使用产品过程中，如果产品出现非人为原因的质量问题，且在购买之日起，开始算起的30天内，可以免费更换一台新产品。（不含运费）。

2、人为损坏（如：跌落摔损，进水，私拆等非正常使用造成）的产品及保修期过期的产品，本着节约环保的原则，我们将为您提供维修服务，维修费用根据实际情况而定。

3、如您在使用过程中遇到任何问题，请登录JOYO官方网站，查阅产品，其他常见问题或咨询。

地址：深圳市龙华区大浪街道华荣路1号JOYO大厦

电话：0755-29576390

www.joyoaudio.com

包装清单

主机x1
电源适配器x1
电源线x1
说明书x1

JOYO
ESEL JOYO ENJOY MUSIC
JOYO TECHNOLOGY CO.,LTD
Address: 2/F, Lishu Industry Building, Dalang Division, Longhua District, Shenzhen, China
www.joyoaudio.com Email:audio@joyoaudio.com Tel: 0086-755-29576390

Specifications

AC adapter input voltage: AC 100~240V 50-60Hz
Built-in battery: 1.2V/2500mAh(Lithium battery)
AC adapter output voltage: DC 9V/3A
RMS power: 6W（4W+1W）
Guitar channel input impedance: >6.7dBV
Weight: 600g
Effects-guitar channel: DELAY(500ms at maximum)
Dimensions: 156(Length)X103(Width)X75(Height)mm

Package contents:

JAM BUDDY x1
Power adapter x1
Power cord x1
User manual x1

Instructions

1.Connect your guitar to JAM BUDDY
2.Turn on the power switch
3.Power indicator: Green colored indicator on the left side of the unit indicates the power is on and the unit is ready to work. Yellow colored indicator on the left side of the unit indicates the unit is in standby mode.
4.ROCK NOW! You can adjust the knobs for TONE, DRIVE GAIN, CLEAN, PRESENCE and MASTER VOLUME to get appropriate guitar sound by playing.
5.You can choose your favorite tone channel by activating the corresponding channel switch. When the specific channel is activated, the channel indicator will be on.
6.CLASSIC or HIGH GAIN mode can be selected for the overdrive channel distortion circuit. When the LED is on, it indicates the overdrive channel distortion circuit is activated. When the LED is off, it indicates the overdrive channel distortion circuit is deactivated.
7.JAM BUDDY is equipped with a Bluetooth audio receiver, which allows you to connect to your Bluetooth device and play music wirelessly. Once connected, you can play music from your device through JAM BUDDY's speaker system. Please note that the Bluetooth connection is only for playback and does not support calls.
8.JAM BUDDY is equipped with a 3.5mm stereo headphone jack, which allows you to connect headphones and play music privately. Please note that when headphones are connected, the speaker will be muted.



Charge

Power on JAM BUDDY. Power indicator connects between line and ground. Power indicator will be on when the unit is working. Power indicator will be on when the unit is in standby mode.



Bluetooth connection

1.Turn on the Bluetooth of the device to be connected to JAM BUDDY.
2.Search for Bluetooth devices on the device to be connected to JAM BUDDY, such as "JAM BUDDY".
3.Click to connect to JAM BUDDY. When the connection is successful, the Bluetooth indicator will be on.



Panel



1. Delay / reverb control knob for pedal effect
2. Feedback control knob for delay effect
3. Delay time control knob for delay effect
4. Master volume knob
5. Tone control knob
6. Drive control knob
7. Clean control knob
8. Presence control knob
9. Master volume knob
10. Bluetooth indicator: When the Bluetooth function of JAM BUDDY is activated, the Bluetooth indicator is blue.
11. Bluetooth switch: Turn on/off JAM BUDDY's Bluetooth function.
12. Power switch: turn on/off JAM BUDDY.
13. Channel switch: Select the channel you want to use.
14. Clean channel indicator
15. Overdrive channel indicator
16. Overdrive channel mode selection button
17. Power indicator: turn on/off JAM BUDDY.
18. Line input jack: Connect to the audio source, such as electric guitar, electric bass or audio.
19. Line output jack: Connect to the amplifier or speaker.
20. Power supply jack: Connect to the power adapter.

Bluetooth connection

1. Turn on the Bluetooth function of the device to be connected to JAM BUDDY.
2. Search for Bluetooth devices on the device, such as "JAM BUDDY".
3. Click to connect to JAM BUDDY. When the connection is successful, the Bluetooth indicator will be on.

Charge

Power on JAM BUDDY. Power indicator connects between line and ground. Power indicator will be on when the unit is working. Power indicator will be on when the unit is in standby mode.

Bluetooth connection

1. Turn on the Bluetooth function of the device to be connected to JAM BUDDY.
2. Search for Bluetooth devices on the device, such as "JAM BUDDY".
3. Click to connect to JAM BUDDY. When the connection is successful, the Bluetooth indicator will be on.

Panel

1. Delay / reverb control knob for pedal effect
2. Feedback control knob for delay effect
3. Delay time control knob for delay effect
4. Master volume knob
5. Tone control knob
6. Drive control knob
7. Clean control knob
8. Presence control knob
9. Master volume knob
10. Bluetooth indicator: When the Bluetooth function of JAM BUDDY is activated, the Bluetooth indicator is blue.
11. Bluetooth switch: Turn on/off JAM BUDDY's Bluetooth function.
12. Power switch: turn on/off JAM BUDDY.
13. Channel switch: Select the channel you want to use.
14. Clean channel indicator
15. Overdrive channel indicator
16. Overdrive channel mode selection button
17. Power indicator: turn on/off JAM BUDDY.
18. Line input jack: Connect to the audio source, such as electric guitar, electric bass or audio.
19. Line output jack: Connect to the amplifier or speaker.
20. Power supply jack: Connect to the power adapter.

Instructions

1.Connect your guitar to JAM BUDDY
2.Turn on the power switch
3.Power indicator: Green colored indicator on the left side of the unit indicates the power is on and the unit is ready to work. Yellow colored indicator on the left side of the unit indicates the unit is in standby mode.
4.ROCK NOW! You can adjust the knobs for TONE, DRIVE GAIN, CLEAN, PRESENCE and MASTER VOLUME to get appropriate guitar sound by playing.
5.You can choose your favorite tone channel by activating the corresponding channel switch. When the specific channel is activated, the channel indicator will be on.
6.CLASSIC or HIGH GAIN mode can be selected for the overdrive channel distortion circuit. When the LED is on, it indicates the overdrive channel distortion circuit is activated. When the LED is off, it indicates the overdrive channel distortion circuit is deactivated.
7.JAM BUDDY is equipped with a Bluetooth audio receiver, which allows you to connect to your Bluetooth device and play music wirelessly. Once connected, you can play music from your device through JAM BUDDY's speaker system. Please note that the Bluetooth connection is only for playback and does not support calls.
8.JAM BUDDY is equipped with a 3.5mm stereo headphone jack, which allows you to connect headphones and play music privately. Please note that when headphones are connected, the speaker will be muted.

Charge

Power on JAM BUDDY. Power indicator connects between line and ground. Power indicator will be on when the unit is working. Power indicator will be on when the unit is in standby mode.

Bluetooth connection

1. Turn on the Bluetooth function of the device to be connected to JAM BUDDY.
2. Search for Bluetooth devices on the device, such as "JAM BUDDY".
3. Click to connect to JAM BUDDY. When the connection is successful, the Bluetooth indicator will be on.

Panel

1. Delay / reverb control knob for pedal effect
2. Feedback control knob for delay effect
3. Delay time control knob for delay effect
4. Master volume knob
5. Tone control knob
6. Drive control knob
7. Clean control knob
8. Presence control knob
9. Master volume knob
10. Bluetooth indicator: When the Bluetooth function of JAM BUDDY is activated, the Bluetooth indicator is blue.
11. Bluetooth switch: Turn on/off JAM BUDDY's Bluetooth function.
12. Power switch: turn on/off JAM BUDDY.
13. Channel switch: Select the channel you want to use.
14. Clean channel indicator
15. Overdrive channel indicator
16. Overdrive channel mode selection button
17. Power indicator: turn on/off JAM BUDDY.
18. Line input jack: Connect to the audio source, such as electric guitar, electric bass or audio.
19. Line output jack: Connect to the amplifier or speaker.
20. Power supply jack: Connect to the power adapter.

Specifications

AC adapter input voltage:	AC 100~240V 50-60Hz
Built-in battery:	1.2V/2500mAh(Lithium battery)
AC adapter output voltage:	DC 9V/3A
RMS power:	6W（4W+1W）
Guitar channel input impedance:	>6.7dBV
Weight:	600g
Effects-guitar channel:	DELAY(500ms at maximum)
Dimensions:	156(Length)X103(Width)X75(Height)mm

Package contents:

JAM BUDDY x1
Power adapter x1
Power cord x1
User manual x1

JOYO
ESEL JOYO ENJOY MUSIC
JOYO TECHNOLOGY CO.,LTD
Address: 2/F, Lishu Industry Building, Dalang Division, Longhua District, Shenzhen, China
www.joyoaudio.com Email:audio@joyoaudio.com Tel: 0086-755-29576390

Thanks for purchasing JAM BUDDY!

Thank you for choosing JOYO products to develop this pocketed size product for JAM BUDDY! Dual channel 24bit guitar amp

Combining guitar playback with a thousand high frequency sampling rate to be sound at 2.4 audio speakers and also 6 different types of effects, including delay and reverb, JAM BUDDY can be used as a guitar amplifier, a guitar speaker, and a guitar effects device. It can also be used as a Bluetooth speaker to play music from your phone, tablet, computer and other devices, so you can practice guitar with your favorite songs anytime, anywhere.

JAM BUDDY has a rechargeable battery, it lasts on delay and reverb for about 6 hours, and it lasts on guitar amp for about 4 hours. It is very portable, you can put it in your backpack and take it with you when you travel.

JAM BUDDY's compact design and portable size make it easy to use. Whether you're at home, in the studio, or on the go, JAM BUDDY is the perfect companion for guitarists who want to practice and perform with high-quality sound and convenience.

Panel:

1. Delay / reverb control knob for pedal effect
2. Feedback control knob for delay effect
3. Delay time control knob for delay effect
4. Master volume knob
5. Tone control knob
6. Drive control knob
7. Clean control knob
8. Presence control knob
9. Master volume knob
10. Bluetooth indicator: When the Bluetooth function of JAM BUDDY is activated, the Bluetooth indicator is blue.
11. Bluetooth switch: Turn on/off JAM BUDDY's Bluetooth function.
12. Power switch: turn on/off JAM BUDDY.
13. Channel switch: Select the channel you want to use.
14. Clean channel indicator
15. Overdrive channel indicator
16. Overdrive channel mode selection button
17. Power indicator: turn on/off JAM BUDDY.
18. Line input jack: Connect to the audio source, such as electric guitar, electric bass or audio.
19. Line output jack: Connect to the amplifier or speaker.
20. Power supply jack: Connect to the power adapter.

Instructions

1.Connect your guitar to JAM BUDDY
2.Turn on the power switch
3.Power indicator: Green colored indicator on the left side of the unit indicates the power is on and the unit is ready to work. Yellow colored indicator on the left side of the unit indicates the unit is in standby mode.
4.ROCK NOW! You can adjust the knobs for TONE, DRIVE GAIN, CLEAN, PRESENCE and MASTER VOLUME to get appropriate guitar sound by playing.
5.You can choose your favorite tone channel by activating the corresponding channel switch. When the specific channel is activated, the channel indicator will be on.
6.CLASSIC or HIGH GAIN mode can be selected for the overdrive channel distortion circuit. When the LED is on, it indicates the overdrive channel distortion circuit is activated. When the LED is off, it indicates the overdrive channel distortion circuit is deactivated.
7.JAM BUDDY is equipped with a Bluetooth audio receiver, which allows you to connect to your Bluetooth device and play music wirelessly. Once connected, you can play music from your device through JAM BUDDY's speaker system. Please note that the Bluetooth connection is only for playback and does not support calls.
8.JAM BUDDY is equipped with a 3.5mm stereo headphone jack, which allows you to connect headphones and play music privately. Please note that when headphones are connected, the speaker will be muted.

Charge

Power on JAM BUDDY. Power indicator connects between line and ground. Power indicator will be on when the unit is working. Power indicator will be on when the unit is in standby mode.

Bluetooth connection

1. Turn on the Bluetooth function of the device to be connected to JAM BUDDY.
2. Search for Bluetooth devices on the device, such as "JAM BUDDY".
3. Click to connect to JAM BUDDY. When the connection is successful, the Bluetooth indicator will be on.

Important safety instructions

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

To prevent fire or shock hazard, do not expose this appliance to rain or moisture.

WARNING:
To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

To disconnect the mains supply completely, the power supply cord must be removed from the mains, or the appliance inlet on the apparatus.

The mains plug of the power supply cord shall remain readily operable.

To prevent damage which may result in fire or shock hazard, do not expose cord to excessive bending, crushing, or placement of heavy items on it.

Do not expose the apparatus to excessive smoke, dust, mechanical vibration, or shock.

Do not place in an enclosed area such as a bookcase or cabinet, which may impede the cooling through the ventilation openings.

Do not place sources of naked flames, such as lighted candles, on the apparatus.

Do not place containers containing liquid on the apparatus.

Use only in moderate climates.

画版说明

1. 延时效果器 / 混响效果音量钮；
2. 延时效果器反馈深度调节旋钮；
3. 延时效果器延时时间调节旋钮；
4. 总输出音量调节旋钮；
5. 音色核心处理音量钮；
6. 过载通道增益调节旋钮；
7. 清音通道增益调节旋钮；
8. 蓝牙指示灯：当JAM BUDDY的蓝牙功能被打开时，蓝牙指示灯点亮为蓝色灯。
9. 电源/电池电量指示灯：开启JAM BUDDY后，电源指示灯点亮为蓝色灯,当电池电量不足时,指示灯将开始持续以每秒两指闪烁的方式，以提醒JAM BUDDY将自动关机。
10. 音色通道模式选择 **公共**：当您离这载模式被选中时音色通道会以红色。
11. 高增益模式开关 **公共**：当高增益模式被选中时，该指示灯点亮。
12. 电源开关：开启关闭JAM BUDDY设备的电源。
13. 蓝牙开关：开启关闭JAM BUDDY的蓝牙功能。
14. 过载通道指示灯：
15. 清音通道指示灯：
16. 过载通道模式选择按钮：
17. 通道切换按钮：
18. 立体输入接口：
19. 环境输出接口：注意，耳机接入后，本机的喇叭输出将自动被切断。
20. 电源接口：连接电源适配器的接口。

基本操作说明

1 将吉他与JAM BUDDY连接

2 打开电源开关

3 电源指示灯：清音通道指示灯与开关过载模式指示灯同时亮起/熄灭表示：本机开机状态正在等待音通道

4 ROCK NOW! 您可根据您的演奏需求调节TONE、DRIVE GAIN、CLEAN、PRESENCE和MASTER VOLUME旋钮来获得合适的吉他音量。

5 您可通过操作通道选择按钮来选择您需要的音色通道。当指示灯亮起表示选择了：对应的通道音色处于启动状态。

6 您还可以通过操作过载通道开关选择踏板来调整DRIVE通道，使其工作在CLASSIC模式或者HIGH GAIN模式。当指示灯熄灭表示选择了：对应的模式处于关闭状态。

7. JAM BUDDY为您提供了蓝牙无线输出接口，您可以通过此接口连接耳机，这样您就可以实现静音练习或者演奏音乐，并且不会打扰到别人。

8 JAM BUDDY内置一只标准的3.5mm立体声耳机输出接口，您可以通过此接口连接耳机，这样您就可以实现静音练习或者演奏音乐，并且不会打扰到别人。

注意：如果您正在使用JAM BUDDY的DRIVE通道，请尽量避免将JAM BUDDY的音量旋钮调整在过高位置，这样可能会引起啸叫。

蓝牙连接

JAM BUDDY内建有蓝牙通信单元，你可以使用带有蓝牙功能的设备与JAM BUDDY进行连接并播放音乐。要使用本功能，您可以按照下面的方式来操作您的JAM BUDDY。

①打开JAM BUDDY蓝牙开关，蓝牙指示灯点亮为蓝色表示待配对状态。

②打开移动设备的蓝牙功能，在设备列表中找到「JAM BUDDY」，并进行配对，成功配对后，JAM BUDDY的蓝牙指示灯将保持常亮状态。

充电

在使用JAM BUDDY过程中，如果电源指示灯变成黄色灯闪烁时，则表示您需要给JAM BUDDY充电了，为了不影响内置电池，请不要长期让本机处于低电状态工作，如不使用，请将电池充满存放。

注意事项

①将电源适配器接通JAM BUDDY电源接口进行充电。

②为JAM BUDDY充电时，充电指示灯点亮为红色灯。

③当JAM BUDDY充满电后充电指示灯熄灭。

注意事项 请使用本产品配备的电源适配器进行充电。

温馨提示： 如果电池已经完满电，即电池使用时间不足1小时，说明电池已经老化，您需要更换新电池再使用。

电气参数

AC适配器输入电压： AC100~240V 50~60Hz
AC适配器输出电压： DC 9V/3A
内置电池规格： 1.2V/2500mAh(锂电池)
吉他通道输入阻抗： >6.7dBV
RMS功率： (W + W + W)
效果器-吉他通道： DELAY(最大500ms)
重量：600g
体积：156（长）X103（宽）X75（高）mm

产品信息登记

销售商名	姓名
销售商电话	QQ 号
日 期	

产品质量保证卡

产品型号		购买日期	
用户信息	姓名	电话	
	地址		
	邮政编码		
销售单位信息	销售商名称	电话	
	地址		

产品质量保证条款

1、在正常使用产品过程中，如果产品出现非人为原因的质量问题，且在购买之日起，开始算起的30天内，可以免费更换一台新产品。（不含运费）。

2、人为损坏（如：跌落摔损，进水，私拆等非正常使用造成）的产品及保修期过期的产品，本着节约环保的原则，我们将为您提供维修服务，维修费用根据实际情况而定。

3、如您在使用过程中遇到任何问题，请登录JOYO官方网站，查阅产品，其他常见问题或咨询。

地址：深圳市龙华区大浪街道华荣路1号JOYO大厦

电话：0755-29576390

www.joyoaudio.com

包装清单

主机x1
电源适配器x1
电源线x1
说明书x1

JOYO
ESEL JOYO ENJOY MUSIC
JOYO TECHNOLOGY CO.,LTD
Address: 2/F, Lishu Industry Building, Dalang Division, Longhua District, Shenzhen, China
www.joyoaudio.com Email:audio@joyoaudio.com Tel: 0086-755-29576390

JAM BUDDY JOYO 说明书 中英文
尺寸 160*125mm 16页
材质105g铜板纸 交马钉（环保）

Guitar Effect Pedal Guitar Amps Accessories